

Sponsor: Liza Perez / Silvia Gonzalez YS Garments, LLC dba Next Level Apparel 15730 S. Figueroa St. Gardena, CA 90248

Latex Particle Challenge Final Report

Test Article: M100 DARK HEATHER GRAY

Content: 60% Cotton/40% Polyester

Purchase Order: 20200430 Study Number: 1292188-S01 Study Received Date: 23 Apr 2020

> Testing Facility: Nelson Laboratories. LLC

6280 S. Redwood Rd.

Salt Lake City, UT 84123 U.S.A.

Test Procedure(s): Standard Test Protocol (STP) Number: STP0005 Rev 07

Quality Event (QE) Number(s): QE22125 Deviation(s):

Summary: This procedure was performed to evaluate the non-viable particle filtration efficiency (PFE) of the test article. Monodispersed polystyrene latex spheres (PSL) were nebulized (atomized), dried, and passed through the test article. The particles that passed through the test article were enumerated using a laser particle counter.

A one-minute count was performed, with the test article in the system. A one-minute control count was performed, without a test article in the system, before and after each test article and the counts were averaged. Control counts were performed to determine the average number of particles delivered to the test article. The filtration efficiency was calculated using the number of particles penetrating the test article compared to the average of the control values.

The procedure employed the basic particle filtration method described in ASTM F2299, with some exceptions; notably the procedure incorporated a non-neutralized challenge. In real use, particles carry a charge, thus this challenge represents a more natural state. The non-neutralized aerosol is also specified in the FDA guidance document on surgical face masks. All test method acceptance criteria were met. Testing was performed in compliance with US FDA good manufacturing practice (GMP) regulations 21 CFR Parts 210, 211 and 820.

> Test Side: Inside 91.5 cm² Area Tested: Particle Size: 0.1 µm

Laboratory Conditions: 21°C, 25% relative humidity (RH) at 0104; 21°C, 24% RH at 0214;

20°C, 25% RH at 0318; 20°C, 25% RH at 0411

Average Filtration Efficiency: 93.6%

Standard Deviation: 1.45





Brandon Williams electronically approved for

31 May 2020 08:36 (+00:00)

Study Completion Date and Time

Study Director

Curtis Gerow

These results apply to the samples as received and relate only to the test article listed in this report. Reports may not be reproduced except in their entirety. Subject to NL terms and conditions at www.nelsonlabs.com.



Deviation Details: Controls and sample counts were conducted for one minute instead of an average of three one minute counts. This change shortens the total test time for each sample but will still provide an accurate determination of the particle counts. An equilibrate is a dwell period where the challenge is being applied to the test article for a certain period of time before test article counts are counted. The equilibrate period was reduced from 2 minutes to a minimum of 30 seconds which is sufficient time to clear the system of any residual particles, and establish a state of stable equilibrium before sample counts are taken. Test method acceptance criteria were met, results are valid.

Results:

Test Article Number	Test Article Counts	Average Control Counts	Filtration Efficiency (%)
1	1,020	14,898	93.2
2-1 ^a	1,045	11,474	90.9
2-2 ^a	698	11,469	93.9
3	589	11,815	95.0
4	671	12,006	94.4
5	715	12,132	94.1

^a The original result for this test article was unexpected when compared to the other test articles. Investigational testing was performed on the same test article in duplicate and it was determined that the original result was invalid. All valid test results are reported.

brd